

MEGAMIST™



ULTRASONIC HUMIDIFIER USER MANUAL REF. 636143

Before using the humidifier, please read the following instructions carefully.

SAFETY GUIDE:

Warning: This mark reminds the user that this operation bears dangerous voltage or may impose injury to the body.

Caution: This mark reminds the user that this operation is an important operation or maintenance instruction of this product.

Do not dismantle the main base for repair or debugging by yourself.

Do not replace the power cord by yourself.

Keep any harmful object, such as cleaning agent, away from reach of children to avoid entering the unit by mistake.

Any modification or refitting to this unit without definite permission of our factory may cause inconvenience and hazard to the user.

If the unit has abnormal sound or odor in operation, please shut it down immediately and disconnect the power plug. Any repair must be done by a professional repairman.

Do not get the cleaning agent into the mouth or eyes. If the cleaning agent is contacted by mistake, rinse with tap water immediately. In serious cases, take an examination at the hospital.

Before cleaning or moving the unit, please shut it down or disconnect the plug.

When the unit is operating, do not touch the water in the water bath or any part in the water with any part of your body.

Do not operate the unit with an empty water bath.

Do not scratch the ultrasonic oscillator with a hard object.

Do not clean the transducer with a cleaning agent not manufactured or whose manufacture is supervised by our company.

Do not let water flow or splash into the base to avoid damaging the internal parts.

In order that this unit can operate properly and unnecessary accidents can be avoided, please pay attention to the environment of installation.

1. Put the unit at a firm and flat place, avoid inclination and keep it steady.
2. Place the unit away from any heat source, such as a furnace, avoid direct sunlight.
3. Place the unit away from furniture and electric appliances/avoid direct spraying of mist onto the furniture and electric appliances, otherwise they will become damp or attached with "white powder"
4. Place the unit in normal room temperatures. Avoid operating the unit in chilly environments to avoid damage to the unit. If there is freezing inside, do not start unit until the ice has been cleared or melted.

SUGGESTION FOR USER

Humidify with cool boiled water or distilled water. Clean the transducer, water tank, base on a weekly basis. Replace the used water in the water frequently to keep the unit clean. When the unit is not to be used for a long time, do not store water in the water and water bath. During storage, clean, mop up or air-dry all parts and then place them in the original package.

PROPER OPERATION

- Place the body horizontally at a suitable place.
- Take out and overturn the water tank, screw off the tank cover as indicated by the arrow at "Add Water Here", inject clean tap water.
- Screw down the cover, wipe off water drops around the water tank and mount the water tank properly.
- Connect the unit to a AC power supply, turn on the power switch and the humidifying indicator will be illuminated.
- There is no staged adjustment of humidifying capacity, which is set to the dryness of your room.
- When there is no water in the water tank, the built-in safety device will disconnect the atomization circuit automatically, when there is no spray output from the spray nozzle and the water depletion indicator is illuminated (two colors of the same indicator). To continue the operation, please cut off the power and replenish the water tank.

OPERATING PRECAUTIONS

- Do not add hot water of above 40°C to the water tank and water bath to avoid discoloration or distortion.
 - Do not let water flow into the body from the air outlet. Wipe off any water outside the body with dry cloth.
 - When the room temperature is below 0°C, please empty the water tank and water bath, the icing of water should damage the components.
 - Do not place metals, chemicals and detergents into the water bath, otherwise there might be poor atomization.
 - When there is much water in the water bath, do not move it about, otherwise water might overflow and flow into the body to cause troubles.
 - Do not put the unit at a place with strong light or direct hot air radiation.
 - Do not place the unit at an airport and try to keep it away from furniture and electric appliances.
 - Do not add water into the water bath directly.
 - When the unit is not to be used for a long time, please cut off the power and unplug the plug (this unit does not have to be grounded).
 - Never pour out the water remaining in the water bath without the power turned off, otherwise the transducer will be burned out immediately.
 - When the water tank is fully loaded, the unit can operate for 7-12 hours continuously without replenishment.
- Safety Precautions
- Do not turn on the plug with a wet hand, otherwise there might be the risk of electric shock.
 - When the body is inclined, please handle this with the power cut off.
 - Do not touch the transduction piece upon starting, otherwise you will have the feel of pain.
 - Do not disassemble the unit without cutting off the power to avoid an electric shock.
 - Do not replace the power cord without authorization.

MEGAMIST™

ULTRASONIC HUMIDIFIER USER MANUAL REF. 636143

Before using the humidifier, please read the following instructions carefully.



MAINTENANCE AND CLEANING

Before cleaning, be sure to cut off the power and unplug the plug.

- Cleaning of water tank(once every 2-3 weeks)

Screw off the water tank cover, wipe off the scale in it and rinse off with water.

- Cleaning of water bath (once a week)

If there is scale in the water bath, wipe the bath with soft cloth dipped with cleaning agent, and rinse off with water.

- External cleaning of humidifier

Rinse the soft cloth in warm water of below 40℃, wipe off the surface stain. The spray nozzle can be flushed with water directly.

STORAGE

When the unit is not to be used for a long time, clean and dry the unit, store in a dry place in the original package.

Keep in Mind:

a. Never touch the oscillating transduction piece with a sharp hard tool. Clean it with wet cloth only.

b. Do not wipe the surface with cloth dipped with chemical solvent, gasoline, kerosene or polishing powder.

c. Do not clean the unit with any detergent, use clean water.

d. During cleaning, avoid water entry into the body, the internal electric components should become damp and faulty.

e. Do not remove the body components.

TROUBLESHOOTING

ABNORMAL SYMPTOM	CAUSE	HANDLING
Indicator not illuminated, no air, no fog	The power plug is not properly plugged The power switch is not turned on	Plug the power plug properly Turn on the power switch
Indicator illuminated, with air, no fog	There is no water in the water tank The automatic constant humidity knob is not turned on The water level float cap is not held down	Top up the water tank Turn the automatic constant humidity Knob clockwise Hold down the water level float cap
Spray with odor	New unit The water in the tank is not clean	Open the water tank Place at a shade for 12 hours Clean or replace the water tank
Indicator illuminated, no air, no fog	The water level in the water tank is too high	Pour out some water in the water tank. Screw down the water tank cover
Small fog output	There is lime formation on the transducer The water is dirty or has been stored too long	Clean the transducer Replace with clean water



This product conforms to all European and US standards.
Este producto cumple toda la normativa Europea y de EEUU.
MADE IN CHINA